

PARAFIN WAX

Code : G813



- Paraffin wax in engineering testing laboratories is used for embedding and preserving samples, especially in materials like soil, rock, and biological specimens, for microscopic examination. It is also used in certain tests to create molds or as a sealing material to protect samples during storage or transportation.

ORDERING INFORMATION

Item	Code
TRICHLOROETHYLENE	G801X00XH
METHYLENE BLUE POWDER - 100 g	G802X00XH
SULPHUR	G803X00XH
GRAPHITE	G804X00XH
SODIUM SULFATE	G805X00XH

MAGNESIUM SULFATE	G806X00XH
BARIUM CHLORIDE	G807X00XH
CALCIUM CHLORIDE	G808X00XH
SODIUM HYDROXIDE	G809X00XH
FORMALDEHYDE (Stock Solution)	G810X00XH
SODIUM HEXAMETAPHOSPHATE	G811X00XH
SILICA GEL	G812X00XH
PARAFIN WAX	G813X00XH
KAOLINITE	G814X00XH
QUANTAB CHLORIDE TITRATOR 1175 TYPE	G815X00XH
QUANTAB CHLORIDE TITRATOR 1176 TYPE	G816X00XH