
ASPHALT > MARSHALL STABILITY

MARSHALL STABILITY TESTING MACHINE (Automatic)

Code : A001A



will be added soon ...

TECHNICAL SPECIFICATIONS

will be added soon ...

ORDERING INFORMATION

Item Name	Item Code
MARSHALL STABILITY TESTER - Automatic	A001A05XU
MARSHALL STABILITY TESTER - Load Ring	A001L05XU
MARSHALL STABILITY TESTER - Digital	A001M05XU

BREAKING HEAD for MARSHALL STABILITY TEST - 4"	A001P001H
BREAKING HEAD for MARSHALL STABILITY TEST - 6"	A001P002H
INDIRECT TENSILE STRENGTH APPARATUS (Lottman Method)	A001P003H
ELECTRONIC BOARD (PCB) for A001A05XU	A001P004H
SPARE LOAD/DEFORMATION INDICATOR for A001M	A001P005H
SPARE MOTOR THREADED SHAFT for A001	A001P006H
SPARE MOTOR for A001	A001P007H
SPARE GEARBOX for A001	A001P008H